



DP 212

Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864
 E-mail: info@dinopaoli.com - Website: www.dinopaoli.com

- | | | | |
|-----------------------------------------|------------------------------|-----------------------------------|----------------------------------------|
| 1 Hammer Case Lock Washer | 13 Hammer Case Gasket | 26 Rear End Plate | 39 Valve Pin Bushing |
| 2 Hammer Case Cap Screw | 14 Motor Housing | 27 Vane | 40 Trigger Pin |
| 3 Hammer Case | 15 Front Rotor Bearing | 28 Rotation Reverse Shaft | 41 Trigger |
| 4 Hammer Case Oil Seal | 16 Front End Plate | 29 Rotation Reverse Shaft Seal | 42 Rotation Reverser Pin |
| 5 Hammer Case Bushing | 17 Front Cylinder Dowel | 30 Rotation Reverse Shaft Bushing | 43 Rotation Reverser Spring |
| 6 3/4" Socket Retaining Ring | 18 Cylinder | 31 Silencer | 44 Rotation Reverser Grub Screw |
| 7 3/4" Socket Retainer O-ring | 19 Rotor | 32 Anchor Pin Circlip | A Whole Motor Housing (14;28+30;32+44) |
| 8 Standard Anvil Shank (3/4"sq. drive) | 20 Rear Cylinder Dowel | 33 Air Filter | B Whole Hammer case (3;4;5) |
| 8L Extended Anvil Shank (3/4"sq. drive) | 21 Housing Cover Gasket | 34 Valve Spring | C Front End Plate + Bearing (15;16) |
| 9 Hammer Frame | 22 Housing Cover Screw | 35 Stainless Ball | D Rear End Plate + Bearing (25;26) |
| 10 Hammer | 23 Housing Cover Lock Washer | 36 Valve Seat | E Air Inlet Valve (32+37) |
| 11 Hammer Pin | 24 Housing Cover | 37 Air Inlet Reducer | F Anvil Shank +Ring +O-ring (6;7;8/8L) |
| 12 Hammer Frame Rear Washer | 25 Rear Rotor Bearing | 38 Valve Pin | |