



# DP 213

Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY  
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864  
 E-mail: [info@dinopaoli.com](mailto:info@dinopaoli.com) - Website: [www.dinopaoli.com](http://www.dinopaoli.com)

- |    |                                      |    |                           |    |                                |    |                                      |
|----|--------------------------------------|----|---------------------------|----|--------------------------------|----|--------------------------------------|
| 1  | Hammer Case Lock Washer              | 14 | Hammer Case O-ring        | 28 | Rear Rotor Bearing             | 42 | Valve Pin Bushing                    |
| 2  | Hammer Case Cap Screw                | 15 | Motor Housing             | 29 | Rear End Plate                 | 43 | Trigger Pin                          |
| 3  | Hammer Case                          | 16 | Front Rotor Bearing       | 30 | Vane                           | 44 | Trigger                              |
| 4  | Hammer Case Oil Seal                 | 17 | Front End Plate Oil Seal  | 31 | Rotation Reverse Shaft         | 45 | Rotation Reverser Pin                |
| 5  | Hammer Case Bushing                  | 18 | Front End Plate O-ring    | 32 | Rotation Reverse Shaft Seal    | 46 | Rotation Reverser Spring             |
| 6  | 3/4" Socket Retaining Ring           | 19 | Front End Plate           | 33 | Rotation Reverse Shaft Bushing | 47 | Rotation Reverser Grub Screw         |
| 7  | 3/4" Socket Retainer O-ring          | 20 | Front Cylinder Dowel      | 34 | Silencer                       | A  | Whole Motor Housing (15;31+33;35+47) |
| 8  | Standard Anvil Shank (3/4"sq. drive) | 21 | Cylinder                  | 35 | Anchor Pin Circlip             | B  | Whole Hammer Case (3;4;5)            |
| 8L | Extended Anvil Shank (3/4"sq. drive) | 22 | Rotor                     | 36 | Air Filter                     | C  | Front End Plate + Bearing (16;17;19) |
| 9  | Hammer Frame                         | 23 | Rear Cylinder Dowel       | 37 | Valve Spring                   | D  | Rear End Plate + Bearing (28;29)     |
| 10 | Hammer                               | 24 | Housing Cover Gasket      | 38 | Stainless Ball                 | E  | Air Inlet Valve (35+40)              |
| 11 | Hammer Pin                           | 25 | Housing Cover Screw       | 39 | Valve Seat                     | F  | Anvil Shank +Ring +O-ring (6;7;8/8L) |
| 12 | Hammer Frame Rear Washer             | 26 | Housing Cover Lock Washer | 40 | Air Inlet Reducer              |    |                                      |
| 13 | Hammer Case Gasket                   | 27 | Housing Cover             | 41 | Valve Pin                      |    |                                      |