



# DP 215

Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY  
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864  
 E-mail: [info@dinopaoli.com](mailto:info@dinopaoli.com) - Website: [www.dinopaoli.com](http://www.dinopaoli.com)

- |    |                                      |    |                        |    |                                |    |                                      |
|----|--------------------------------------|----|------------------------|----|--------------------------------|----|--------------------------------------|
| 1  | Hammer Case Cap Screw                | 14 | Roller                 | 28 | Housing Cover Lock Washer      | 42 | Valve Seat                           |
| 2  | Hammer Case Lock Washer              | 15 | Clutch Housing         | 29 | Rear Cylinder Dowel            | 43 | Valve Seat Support                   |
| 3  | Hammer Case                          | 16 | Clutch Housing Bearing | 30 | Vane                           | 44 | Valve Pin                            |
| 4  | Hammer Case Bushing                  | 17 | Hammer Case Gasket     | 31 | Front Cylinder Dowel           | 45 | Valve Pin Bushing                    |
| 5  | 3/4" Socket Retaining Ring           | 18 | Motor Housing          | 32 | Rotation Reverse Shaft Seal    | 46 | Trigger Pin                          |
| 6  | 3/4" Socket Retainer O-ring          | 19 | Housing Cover Gasket   | 33 | Rotation Reverse Shaft         | 47 | Trigger                              |
| 7  | Standard Anvil Shank (3/4"sq. drive) | 20 | Front Rotor Bearing    | 34 | Rotation Reverse Shaft Bushing | 48 | Rotation Reverser Pin                |
| 7L | Extended Anvil Shank (3/4"sq. drive) | 21 | Front End Plate        | 35 | Oil Felt Washer                | 49 | Rotation Reverser Spring             |
| 8  | Clutch Shaft                         | 22 | Rotor                  | 36 | Oil Felt                       | 50 | Rotation Reverser Grub Screw         |
| 9  | Clutch Spring                        | 23 | Cylinder               | 37 | Oil Plug                       | A  | Whole Motor Housing (18;32+50)       |
| 10 | Clutch Plate                         | 24 | Rear End Plate         | 38 | Air Inlet Reducer              | B  | Whole Hammer Case (3;4)              |
| 11 | Clutch Cam                           | 25 | Rear Rotor Bearing     | 39 | Air Filter                     | C  | Front End Plate + Bearing (20;21)    |
| 12 | Clutch Housing Bushing               | 26 | Housing Cover          | 40 | Valve Spring                   | D  | Rear End Plate + Bearing (24;25)     |
| 13 | Pin Roller                           | 27 | Housing Cover Screw    | 41 | Stainless Ball                 | E  | Anvil Shank +Ring +O-ring (5;6;7/7L) |