



DP 220

Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864
 E-mail: info@dinopaoli.com - Website: www.dinopaoli.com

- | | | | | | | | |
|----|------------------------------------|----|---------------------------|----|--------------------------------|----|--------------------------------------|
| 1 | Hammer Case Cap Screw | 15 | Clutch Housing | 30 | Vane | 45 | Valve Pin Bushing |
| 2 | Hammer Case Lock Washer | 16 | Clutch Housing Bearing | 31 | Front Cylinder Dowel | 46 | Trigger Pin |
| 3 | Hammer Case | 17 | Hammer Case Gasket | 32 | Rotation Reverse Shaft Seal | 47 | Trigger |
| 4 | Hammer Case Bushing | 18 | Motor Housing | 33 | Rotation Reverse Shaft | 48 | Rotation Reverser Pin |
| 5 | 1" Socket Retaining Ring | 19 | Housing Cover Gasket | 34 | Rotation Reverse Shaft Bushing | 49 | Rotation Reverser Spring |
| 6 | 1" Socket Retainer O-ring | 20 | Front Rotor Bearing | 35 | Oil Felt Washer | 50 | Rotation Reverser Grub Screw |
| 7 | Standard Anvil Shank (1"sq. drive) | 21 | Front End Plate | 36 | Oil Felt | 51 | 1" Socket Retainer (alternative 5;6) |
| 7L | Extended Anvil Shank (1"sq. drive) | 22 | Rotor | 37 | Oil Plug | A | Whole Motor Housing (18;32+50) |
| 8 | Clutch Shaft | 23 | Cylinder | 38 | Air Inlet Reducer | B | Whole Hammer Case (3;4) |
| 9 | Clutch Spring | 24 | Rear End Plate | 39 | Air Filter | C | Front End Plate + Bearing (20;21) |
| 10 | Clutch Plate | 25 | Rear Rotor Bearing | 40 | Valve Spring | D | Rear End Plate + Bearing (24;25) |
| 11 | Clutch Cam | 26 | Housing Cover | 41 | Stainless Ball | E | Anvil Shank +Ring +O-ring (5;6;7/7L) |
| 12 | Clutch Housing Bushing | 27 | Housing Cover Screw | 42 | Valve Seat | F | Anvil Shank +Ring (7/7L;51) |
| 13 | Pin Roller | 28 | Housing Cover Lock Washer | 43 | Valve Seat Support | | |
| 14 | Roller | 29 | Rear Cylinder Dowel | 44 | Valve Pin | | |