



Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864
 E-mail: info@dinopaoli.com - Website: www.dinopaoli.com

DP 222

1	Hammer Case	13	Hammer Case Gasket	26	Rear End Plate	39	Valve Pin Bushing
2	Hammer Case Cap Screw	14	Motor Housing	27	Vane	40	Trigger Pin
3	Hammer Case Lock Washer	15	Front Rotor Bearing	28	Rotation Reverse Shaft	41	Trigger
4	Hammer Case Oil Seal	16	Front End Plate	29	Rotation Reverse Shaft Seal	42	Rotation Reverser Pin
5	Hammer Case Bushing	17	Front Cylinder Dowel	30	Rotation Reverse Shaft Bushing	43	Rotation Reverser Spring
6	1" Socket Retainer O-ring	18	Cylinder	31	Silencer	44	Rotation Reverser Grub Screw
7	1" Socket Retaining Ring	19	Rotor	32	Anchor Pin Circlip	A	Whole Motor Housing (14;28+30;32+44)
8	Standard Anvil Shank (1"sq.drive)	20	Rear Cylinder Dowel	33	Air Filter	B	Whole Hammer Case (1;4;5)
8L	Extended Anvil Shank (1"sq.drive)	21	Housing Cover Gasket	34	Valve Spring	C	Front End Plate + Bearing (15;16)
9	Hammer Frame	22	Housing Cover Screw	35	Stainless Ball	D	Rear End Plate + Bearing (25;26)
10	Hammer	23	Housing Cover Lock Washer	36	Valve Seat	E	Air Inlet Valve (32+37)
11	Hammer Pin	24	Housing Cover	37	Air Inlet Reducer	F	Anvil Shank +Ring +O-ring (6;7;8/8L)
12	Hammer Frame Rear Washer	25	Rear Rotor Bearing	38	Valve Pin		