



# DP 236

Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY  
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864  
 E-mail: [info@dinopaoli.com](mailto:info@dinopaoli.com) - Website: [www.dinopaoli.com](http://www.dinopaoli.com)

1	Hammer Case Lock Washer	16	Clutch Housing	32	Housing Cover Gasket	48	Valve Pin Bushing
2	Hammer Case Cap Screw	17	Clutch Housing Bearing	33	Housing Cover Screw	49	Trigger Pin
3	Hammer Case	18	Motor Housing	34	Housing Cover Lock Washer	50	Trigger
4	Suspension Shackle	19	Handle Bracket	35	Housing Cover	51	Rotation Reverser Pin
5	Hammer Case Gasket	20	Handle	36	Cylinder	52	Rotation Reverser Spring
6	Hammer case Oil Seal	21	Handle Screw	37	Rotation Reverse Shaft	53	Rotation Reverser Grub Screw
7	Combined Bearing	22	Handle Lock Washer	38	Rotation Reverse Shaft Seal	54	Pin Roller
8	Hammer Case Bushing	23	Handle Screw Nut	39	Rotation Reverse Shaft Bushing	55	Roller
9	1" Socket Retainer	24	Front Rotor Bearing	40	Silencer	A	Whole Motor Housing (18;37+39;41+53)
10	Standard Anvil Shank (1"sq.drive)	25	Front End Plate	41	Anchor Pin Circlip	B	Whole Hammer Case with Bearing (3;6;7)
10L	Extended Anvil Shank (1"sq.drive)	26	Front Cylinder Dowel	42	Air Filter	C	Whole Hammer Case with Bushing (3;6;8)
11	Clutch Shaft	27	Vane	43	Valve Spring	D	Front End Plate + Bearing (24;25)
12	Clutch Spring	28	Rotor	44	Stainless Ball	E	Rear End Plate + Bearing (30;31)
13	Clutch Plate	29	Rear Cylinder Dowel	45	Valve Seat	F	Air Inlet Valve (41+46)
14	Clutch Cam	30	Rear End Plate	46	Air Inlet Reducer	G	Whole Handle (19+23)
15	Clutch Housing Bushing	31	Rear Rotor Bearing	47	Valve Pin	H	Anvil Shank +Ring (9;10/10L)