



# DP 236 SF

Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY  
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864  
 E-mail: [info@dinopaoli.com](mailto:info@dinopaoli.com) - Website: [www.dinopaoli.com](http://www.dinopaoli.com)

- |                                       |                           |                                   |  |
|---------------------------------------|---------------------------|-----------------------------------|--|
| 1 Hammer Case Lock Washer             | 16 Clutch Housing         | 32 Housing Cover Gasket           | 48 Valve Pin Bushing                     |
| 2 Hammer Case Cap Screw               | 17 Clutch Housing Bearing | 33 Housing Cover Screw            | 49 Trigger Pin                           |
| 3 Hammer Case                         | 18 Motor Housing          | 34 Housing Cover Lock Washer      | 50 Trigger                               |
| 4 Suspension Shackle                  | 19 Handle Bracket         | 35 Housing Cover                  | 51 Rotation Reverser Pin                 |
| 5 Hammer Case Gasket                  | 20 Handle                 | 36 Cylinder                       | 52 Rotation Reverser Spring              |
| 6 Hammer case Oil Seal                | 21 Handle Screw           | 37 Rotation Reverse Shaft         | 53 Rotation Reverser Grub Screw          |
| 7 Combined Bearing                    | 22 Handle Lock Washer     | 38 Rotation Reverse Shaft Seal    | 54 Pin Roller                            |
| 8 Hammer Case Bushing                 | 23 Handle Screw Nut       | 39 Rotation Reverse Shaft Bushing | 55 Roller                                |
| 9 1" Socket Retainer                  | 24 Front Rotor Bearing    | 40 Silencer                       | A Whole Motor Housing (18;37÷39;41÷53)   |
| 10 Standard Anvil Shank (1"sq.drive)  | 25 Front End Plate        | 41 Anchor Pin Circlip             | B Whole Hammer Case with Bearing (3;6;7) |
| 10L Extended Anvil Shank (1"sq.drive) | 26 Front Cylinder Dowel   | 42 Air Filter                     | C Whole hammer Case with Bushing (3;6;8) |
| 11 Clutch Shaft                       | 27 Vane                   | 43 Valve Spring                   | D Front End Plate + Bearing (24;25)      |
| 12 Clutch Spring                      | 28 Rotor                  | 44 Stainless Ball                 | E Rear End Plate + Bearing (30;31)       |
| 13 Clutch Plate                       | 29 Rear Cylinder Dowel    | 45 Valve Seat                     | F Air Inlet Valve (41÷46)                |
| 14 Clutch Cam                         | 30 Rear End Plate         | 46 Air Inlet Reducer              | G Whole Handle (19÷23)                   |
| 15 Clutch Housing Bushing             | 31 Rear Rotor Bearing     | 47 Valve Pin                      | H Anvil Shank +Ring (9;10/10L)           |