



DP 255

Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864
 E-mail: info@dinopaoli.com - Website: www.dinopaoli.com

- | | | | |
|---|-----------------------------------|------------------------------|--|
| 1 Hammer Case Lock Washer | 17 Clutch Housing | 34 Eyebolt | 51 Pin Valve |
| 2 Hammer Case Cap Screw | 18 Clutch Housing Bushing | 35 Housing Cover Screw | 52 Pin Valve Bushing |
| 3 Hammer Case | 19 Hammer Case Gasket | 36 Housing Cover Lock Washer | 53 Trigger Pin |
| 4 Hammer Case Bushing(only with 10) | 20 Motor Housing | 37 Rear Cylinder Dowel | 54 Trigger |
| 5 Combined Bearing (only with 10L) | 21 Handle Lock Washer | 38 Vane | 55 Rotation Reverser Pin |
| 6 Thrust Plate (only with 10L) | 22 Handle Screw | 39 Front Cylinder Dowel | 56 Rotation Reverser Spring |
| 7 1" Socket Retaining Ring | 23 Straight Handle | 40 Front End Plate | 57 Rotation Reverser Grub Screw |
| 8 1" Socket Retainer O-ring | 24 Ring Handle | 41 Front Rotor Bearing | 58 Roller |
| 9 1" Socket Retainer (alternative 7;8) | 25 Rotation Reverse Shaft | 42 Oil Washer | 59 Pin Roller |
| 10 Standard Anvil Shank (1" sq. drive) | 26 Rotation Reverse Shaft Seal | 43 Oil Felt | A Whole Motor Housing (18;23+25;40+55) |
| 10L Extended Anvil Shank (1" sq. drive) | 27 Rotation Reverse Shaft Bushing | 44 Oil Plug | B Hammer Case with Bearing (3;5) |
| 11 Clutch Spring | 28 Housing Cover Gasket | 45 Air Inlet Reducer | C Hammer Case with Bushing (3;4) |
| 12 Clutch Shaft | 29 Rotor | 46 Air Filter | D Front End Plate + Bearing (38;39) |
| 13 Clutch Spring Washer | 30 Cylinder | 47 Valve Spring | E Rear End Plate + Bearing (29;30) |
| 14 Clutch Plate | 31 Rear End Plate | 48 Stainless Ball | F Anvil Shank +Ring +O-ring (7;8;10/10L) |
| 15 Clutch Cam | 32 Rear Rotor Bearing | 49 Valve Seat | G Anvil Shank +Ring (9;10/10L) |
| 16 Clutch Housing Bushing | 33 Housing Cover | 50 Valve Seat Support | |