


# DP 30



Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY  
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864  
 E-mail: [info@dinopaoli.com](mailto:info@dinopaoli.com) - Website: [www.dinopaoli.com](http://www.dinopaoli.com)

1	Hammer Case Cap Screw	16	Pin Roller	31	Housing Cover	46	Valve Pin
2	Hammer Case Lock Washer	17	Clutch Housing Bearing	32	Hanger	47	Trigger Pin
3	Hammer Case	18	Hammer Case Gasket	33	Housing Cover Screw	48	Trigger
4	Combined Bearing	19	Motor Housing	34	Housing Cover Lock Washer	49	Rotation Reverser Pin
5	Thrust Plate	20	Rotation Reverse Bushing	35	Vane	50	Rotation Reverser Spring
6	½" Socket Retaining Ring	21	Rotation Reverse Seal	36	Muffler Foam	51	Rotation Reverser Grub Screw
7	½" Socket Retainer O-ring	22	Rotation Reverse Shaft	37	Silencer Air Filter	A	Whole Motor Housing (19÷22;39;41÷51)
8	½" Socket Retainer (alternative 6;7)	23	Front Rotor Bearing	38	Silencer	B	Whole Motor Housing + Reg. (19÷22;40÷51)
9	Anvil Shank (½" square drive)	24	Front End Plate	39	Air Inlet Reducer	C	Whole Hammer Case (3;4)
10	Clutch Spring	25	Rotor	40	Air Inlet Reducer with Regulator	D	Front End Plate + Bearing (23;24)
11	Clutch Plate	26	Cylinder	41	Air Filter	E	Rear End Plate + Bearing (28;29)
12	Clutch Cam	27	Cylinder Dowel	42	Valve Spring	F	Anvil Shank +Ring +O-ring (6;7;9)
13	Clutch Housing Bushing	28	Rear End Plate	43	Stainless Ball	G	Anvil Shank +Ring (8;9)
14	Clutch Housing	29	Rear Rotor Bearing	44	Valve Seat		
15	Roller	30	Housing Cover Gasket	45	Valve Seat Support		