



Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY  
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864  
 E-mail: [info@dinopaoli.com](mailto:info@dinopaoli.com) - Website: [www.dinopaoli.com](http://www.dinopaoli.com)

# DP 321

- |                                 |                         |                                   |  |
|---------------------------------|-------------------------|-----------------------------------|--|
| 1 Hammer Case Lock Washer       | 17 Handle Screw Nut     | 33 Housing Cover Lock Washer      | 49 Trigger                             |
| 2 Hammer Case Cap Screw         | 18 Handle Washer        | 34 Housing Cover                  | 50 Rotation Reverser Pin               |
| 3 Hammer Case                   | 19 Handle Screw         | 35 Cylinder                       | 51 Rotation Reverser Spring            |
| 4 Suspension Shackle            | 20 Handle Bracket       | 36 Rotation Reverse Shaft         | 52 Rotation Reverser Grub Screw        |
| 5 Hammer Case Gasket            | 21 Ring Handle          | 37 Rotation Reverse Shaft Seal    | 53 Pin Roller                          |
| 6 Hammer Case Oil Seal          | 22 Straight Handle      | 38 Rotation Reverse Shaft Bushing | 54 Roller                              |
| 7 Combined Bearing              | 23 Front Rotor Bearing  | 39 Silencer                       | A Whole Motor Housing (16;36+38;40+52) |
| 8 Anvil Shank (1"1/2 sq. drive) | 24 Front End Plate      | 40 Anchor Pin Circlip             | B Whole Hammer Case (3;6;7)            |
| 9 Clutch Shaft                  | 25 Front Cylinder Dowel | 41 Air Filter                     | C Front End Plate + Bearing (23;24)    |
| 10 Clutch Spring                | 26 Vane                 | 42 Valve Spring                   | D Rear End Plate + Bearing (29;30)     |
| 11 Clutch Plate                 | 27 Rotor                | 43 Stainless Ball                 | E Air Inlet Valve (40+45)              |
| 12 Clutch Cam                   | 28 Rear Cylinder Dowel  | 44 Valve Seat                     | F Whole Ring Handle (17+21)            |
| 13 Clutch Housing Bushing       | 29 Rear End Plate       | 45 Air Inlet Reducer              | G Whole Straight Handle (17+20;22)     |
| 14 Clutch Housing               | 30 Rear Rotor Bearing   | 46 Valve Pin                      |  |
| 15 Clutch Housing Bearing       | 31 Housing Cover Gasket | 47 Valve Pin Bushing              |  |
| 16 Motor Housing                | 32 Housing Cover Screw  | 48 Trigger Pin                    |  |