



# DP 360

Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY  
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864  
 E-mail: [info@dinopaoli.com](mailto:info@dinopaoli.com) - Website: [www.dinopaoli.com](http://www.dinopaoli.com)

- |   |                             |                            |  |
|---|-----------------------------|----------------------------|--|
| 1 Hammer Case Lock Washer               | 17 Clutch Housing Bearing   | 34 Motor Cover Screw       | 51 Valve Pin Bushing                   |
| 2 Hammer Case Cap Screw                 | 18 Hammer Case Gasket       | 35 Motor Cover Lock Washer | 52 Trigger Pin                         |
| 3 Hammer Case                           | 19 Motor Housing            | 36 Rear Cylinder Dowel     | 53 Trigger                             |
| 4 Hammer Case Bushing                   | 20 Handle Washer            | 37 Vane                    | 54 Rotation Reverser Pin               |
| 5 1" Socket Retainer (alternative 6;7)  | 21 Handle Screw             | 38 Front Cylinder Dowel    | 55 Rotation Reverser Spring            |
| 6 1" Socket Retaining Ring              | 22 Straight Handle          | 39 Front End Plate         | 56 Rotation Reverser Grub Screw        |
| 7 1" Socket Retainer O-ring             | 23 Ring Handle              | 40 Front Rotor Bearing     | 57 Roller                              |
| 8 Standard Anvil Shank (1" sq. drive)   | 24 Rotation Reverse Shaft   | 41 Oil Felt Washer         | 58 Pin Roller                          |
| 8L Extended Anvil Shank (1" sq. drive)  | 25 Rotation Reverse Seal    | 42 Oil Felt                | A Whole Motor Housing (19;24+26;41+56) |
| 9 Special Anvil Shank (1 1/2 sq. drive) | 26 Rotation Reverse Bushing | 43 Oil Plug                | B Whole Hammer Case (3;4)              |
| 10 Clutch Spring                        | 27 Motor Cover Gasket       | 44 Air Inlet Reducer       | C Front End Plate + Bearing (39;40)    |
| 11 Clutch Shaft                         | 28 Rotor                    | 45 Air Filter              | D Rear End Plate + Bearing (30;31)     |
| 12 Clutch Spring Washer                 | 29 Cylinder                 | 46 Valve Spring            | E Anvil Shank +Ring +O-ring (6;7;8/8L) |
| 13 Clutch Plate                         | 30 Rear End Plate           | 47 Stainless Ball          | F Anvil Shank +Ring (5;8/8L)           |
| 14 Clutch Cam                           | 31 Rear Rotor Bearing       | 48 Valve Seat              |  |
| 15 Clutch Housing Bushing               | 32 Motor Cover              | 49 Valve Seat Support      |  |
| 16 Clutch Housing                       | 33 Eyebolt                  | 50 Valve Pin               |  |