



Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY  
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864  
 E-mail: [info@dinopaoli.com](mailto:info@dinopaoli.com) - Website: [www.dinopaoli.com](http://www.dinopaoli.com)

# DP 361BG

- |    |                                      |    |                       |    |                                |    |                                     |
|----|--------------------------------------|----|-----------------------|----|--------------------------------|----|-------------------------------------|
| 1  | Hammer Case                          | 17 | Hammer Case Gasket    | 33 | Air Filter                     | 49 | Rotation Reverse Shaft              |
| 2  | Hammer Case Cap Screw                | 18 | Motor Housing         | 34 | Valve Spring                   | 50 | Rotation Reverser Pin               |
| 3  | Hammer Case Lock Washer              | 19 | Eyebolt               | 35 | Stainless Ball                 | 51 | Rotation Reverser Spring            |
| 4  | Hammer Case Bushing                  | 20 | Handle Washer         | 36 | Valve Seat                     | 52 | Rotation Reverser Grub Screw        |
| 5  | Anvil Shank (1 1/2 sq. drive)        | 21 | Handle Screw          | 37 | Valve Seat Support             | 53 | Roller                              |
| 6  | 1" Socket Retaining Ring             | 22 | Straight Handle       | 38 | Valve Pin                      | 54 | Pin Roller                          |
| 7  | 1" Socket Retainer O-ring            | 23 | Ring Handle           | 39 | Valve Pin Bushing              | A  | Whole Motor Housing (18;47-52)      |
| 8  | 1" Socket Retainer (alternative 7;8) | 24 | Front Cylinder Dowel  | 40 | Inside Trigger Handle Screw    | B  | Whole Inside Trigger Handle (29+39) |
| 9  | Anvil Shank (1" sq. drive)           | 25 | Cylinder              | 41 | Inside Trigger Handle Washer   | C  | Whole Hammer Case (1;4)             |
| 10 | Clutch Spring                        | 26 | Rear Cylinder Dowel   | 42 | Rotor                          | D  | Front End Plate + Bearing (44;45)   |
| 11 | Clutch Shaft                         | 27 | Rear End Plate        | 43 | Vane                           | E  | Rear End Plate + Bearing (27;28)    |
| 12 | Clutch Plate                         | 28 | Rear Rotor Bearing    | 44 | Front End Plate                | F  | Anvil Shank +Ring +O-ring (6,7;9)   |
| 13 | Clutch Cam                           | 29 | Inside Trigger Handle | 45 | Front Rotor Bearing            | G  | Anvil Shank +Ring (8;9)             |
| 14 | Clutch Housing Bushing               | 30 | Trigger Pin           | 46 | Inside Trigger Handle Gasket   |    |                                     |
| 15 | Clutch Housing                       | 31 | Trigger               | 47 | Rotation Reverse Shaft Bushing |    |                                     |
| 16 | Clutch Housing Bearing               | 32 | Air Inlet Reducer     | 48 | Rotation Reverse Shaft Seal    |    |                                     |