



DP 381 1" 1/2



Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864
 E-mail: info@dinopaoli.com - Website: www.dinopaoli.com

- | | | | | | | | |
|----|------------------------------------|----|--------------------------------|----|----------------------------|----|---|
| 1 | Hammer Case Eyebolt | 18 | Handle Washer | 35 | Rear Cylinder Dowel | 52 | Trigger Pin |
| 2 | Hammer Case Lock Washer | 19 | Handle Screw | 36 | Vane | 53 | Trigger |
| 3 | Hammer Case Cap Screw | 20 | Rotation Reverse Shaft | 37 | Front Cylinder Dowel | 54 | Rotation Reverser Pin |
| 4 | Greaser | 21 | Rotation Reverse Shaft Seal | 38 | Oil Plug | 55 | Rotation Reverser Spring |
| 5 | Hammer Case (1"1/2 sq. drive) | 22 | Rotation Reverse Shaft Bushing | 39 | Oil Felt | 56 | Rotation Reverser Grub Screw |
| 6 | Hammer Case Bushing (1"1/2 sq.dr.) | 23 | Motor Housing | 40 | Trigger Handle Gasket | 57 | Roller |
| 7 | Anvil Shank (1"1/2 sq. drive) | 24 | Housing Cover Gasket | 41 | Trigger Handle Long Screw | 58 | Pin Roller |
| 8 | Clutch Spring | 25 | Front Rotor Bearing | 42 | Trigger Handle Washer | A | Whole Motor Housing (20+23;38;39;54+56) |
| 9 | Clutch Spring Washer | 26 | Front End Plate | 43 | Trigger Handle Short Screw | B | Whole Trigger Handle (44+53) |
| 10 | Clutch Plate | 27 | Rotor | 44 | Trigger Handle | C | Whole Hammer Case (4+6) |
| 11 | Clutch Shaft | 28 | Cylinder | 45 | Air Inlet Reducer | D | Front End Plate + Bearing (25;26) |
| 12 | Clutch Cam | 29 | Rear End Plate | 46 | Air Filter | E | Rear End Plate + Bearing (29;30) |
| 13 | Clutch Housing Bushing | 30 | Rear Rotor Bearing | 47 | Valve Spring | | |
| 14 | Clutch Housing | 31 | Housing Cover | 48 | Stainless Ball | | |
| 15 | Clutch Housing Bearing | 32 | Eyebolt | 49 | Valve Seat | | |
| 16 | Hammer Case Gasket | 33 | Housing Cover Screw | 50 | Valve Pin | | |
| 17 | Handle | 34 | Housing Cover Lock Washer | 51 | Valve Pin Bushing | | |