



Dino Paoli s.r.l. - Via G. Dorso, 5 - 42100 Reggio nell'Emilia (RE) - ITALY
 Tel.: +39.0522.364.511 / 300.828 - Fax: +39.0522.304.864
 E-mail: info@dinopaoli.com - Website: www.dinopaoli.com

1	Hammer Case Eyebolt	18	Handle Washer	35	Rear Cylinder Dowel	52	Trigger Pin
2	Hammer Case Lock Washer	19	Handle Screw	36	Vane	53	Trigger
3	Hammer Case	20	Rotation Reverse Shaft	37	Front Cylinder Dowel	54	Rotation Reverser Pin
4	Greaser	21	Rotation Reverse Shaft Seal	38	Oil Plug	55	Rotation Reverser Spring
5	Hammer Case (2''sq.drive)	22	Rotation Reverse Shaft Bushing	39	Oil Felt	56	Rotation Reverser Grub Screw
6	Hammer Case Bushing (2''sq.drive)	23	Motor Housing	40	Trigger Handle Gasket	57	Roller
7	Anvil Shank (2''sq.drive)	24	Housing Cover Gasket	41	Trigger Handle Long Screw	58	Pin Roller
8	Clutch Spring	25	Front Rotor Bearing	42	Trigger Handle Washer	A	Whole Motor Housing (20+23;38;39;54+56)
9	Clutch Spring Washer	26	Front End Plate	43	Trigger Handle Short Screw	B	Whole Trigger Handle (44+53)
10	Clutch Plate	27	Rotor	44	Trigger Handle	C	Whole Hammer Case (4+6)
11	Clutch Shaft	28	Cylinder	45	Air Inlet Reducer	D	Front End Plate + Bearing (25;26)
12	Clutch Cam	29	Rear End Plate	46	Air Filter	E	Rear End Plate + Bearing (29;30)
13	Clutch Housing Bushing	30	Rear Rotor Bearing	47	Valve Spring		
14	Clutch Housing	31	Housing Cover	48	Stainless Ball		
15	Clutch Housing Bearing	32	Eyebolt	49	Valve Seat		
16	Hammer Case Gasket	33	Housing Cover Screw	50	Valve Pin		
17	Handle	34	Housing Cover Lock Washer	51	Valve Pin Bushing		